Parts Price List

DeVry "15" 16mm. Sound Projector

PROJECTOR PARTS

Description	Part Number	Shown On Page*	List Price
ARM, takeup reel assembly	14028-CC	21	$12.50
ARM, feed reel assembly	14029-CC	20	12.50
BAFFLE, shutter assembly	14173	17	.45
BASE, projector lamp	14279	17	.30
BELT, motor drive	14319	19	1.25
BELT, take-up and rewind	14207	14	.50
BRACKET assembly, lower	14149	19	.95
BRACKET, bumper	14578-F13	15	.75
BRACKET, face plate assembly	8832	19	.95
BRACKET, pressure shoe (Kit assembly)	8659	18	1.75
BRACKET, pressure plate (Kit assembly)	9218	18	1.75
BRACKET, pilot lamp assembly	14158	19	.20
BRACKET, reel arm storage	14527-P5	Not Shown	.90
BRUSH, motor	14367	Not Shown	.25
BRUSH, governor	14368	Not Shown	.40
BUMPER, rubber	14462	15	.15
CASE, projector	14445-M3C6	Not Shown	40.00
CELL, photo-conductive (In Mounting)	14415	16	7.50
CHAIN, mechanism drive	14320	19	9.00
CONDENSER, .5 mfd. 400 V oil	15506	22	2.35
CONDENSER, .005 mfd. 500 V mica	15962	22	.60
CORD, power extension, 25 ft.	1786	Not Shown	10.50
CORD, speaker extension, 50 ft.	14146	Not Shown	10.00
CORD, projector	14321	14	2.00
COVER, aperture mounting	14026-CC	16	3.00
COVER, exciter lamp	14169-CC	15	3.00
COVER, lamphouse assembly	14129-CC	15	14.00
COVER, mechanism	14582-F13	19	2.50
DRIVE, rewind and take-up assembly	14151	19	6.00
DRIVE, main assembly	14163	19	9.50
DRUM, sound assembly	14105	16	35.00
EXCITER, lamp assembly	14120	18	9.50
FLYWHEEL, sound	14241	19	13.00
FOOT, rubber	14380	15	.15
FRAME, aperture mounting	14134-CC	17	6.00
GEAR, shutter assembly	14162	19	2.00
GEAR, reduction assembly	14112	19	4.25
GOVERNOR, 2 speed	14529-F8	Not Shown	12.00
GUARD, vent	14142-F13	14	1.20
GUARD, take-up and feed belt	14106-F13	19	.45
IDLER, drive assembly	11036-AA	19	1.50
IDLER, fixed chain assembly	14116	19	1.25
KNOB, motor	14430	14	1.00
KNOB, lamphouse	14076	15	.50
LAMP, pilot	13251	15	.40

Prices effective December 1, 1952. Subject to change without prior notice.

*"Shown on Page" refers to page number in DeVry "15" Operating and Service Manual.

PROJECTOR PARTS

Description	Part Number	Shown On Page*	List Price
LAMP, projector, 750 W. 115 V. T-12	462	Not Shown	$ 4.10
LAMP, exciter	399	16	.85
LENS, aspheric condenser	11324	17	3.85
LENS, piano condenser	8996	17	3.50
LENS, sound	11047	16	5.75
LENS, 2'' coated projection	6945	15	26.50
LEVER, Film gate (Kit assembly)	8820	18	1.25
LEVER, framing	9169-M1P1	15	1.10
LOCK, film shoe	11290	16	.35
LOOP SETTER ASSEMBLY	14131	16	2.50
MOTOR, and fan assembly	14123-CC	19	64.50
MOUNT, condenser	14269-M1	17	.85
MOUNT, reflector	14269	17	.85
MOUNTING bracket assembly, takeup	14191-CC	14	3.25
MOUNTING bracket assembly, feed	14192-CC	14	3.25
OIL RESERVOIR ASSEMBLY	14197	17	3.25
PILOT LAMP ASSEMBLY	11252	15	2.30
PLATE, pressure (Kit assembly)	9069-M3	18	3.30
PLATE, aperture assembly	14156-CD	17	13.00
PLUG, Jones	14213	19	1.20
PULLEY, feed and take-up	14202	20, 21	2.50
REEL, shaft assembly	9150-CD	20, 21	3.15
REFLECTOR	11338	17	2.00
REFLECTOR, assembly	14126	17	3.30
RESISTOR, 50 ohm	14337	22	.85
ROLLER, film idler	11349-MP9	15	.35
ROLLER, film guide	11670-MP9	15	.25
ROLLER, sound adjustment assembly	14135	16	9.00
ROLLER, plain sound assembly	14139	16	8.75
ROLLER, idler assembly	11107	19	.65
SCREW, sound flywheel	2289-P5	19	.20
SCREW, thumb	8610-M2P13	18	.15
SCREW, cover	10104-P5	15	.15
SCREW, headless	7076	18	.10
SHAFT, cam assembly	14110	19	8.75
SHAFT, reduction gear	14431	19	1.00
SHAFT, shutter	14372	Not Shown	.90
SHOE, film	11033	15	2.50
SHUTTER, film	14392	17	1.10
SHUTTLE, assembly	8818-CC	17	10.50
SOCKET, projection lamp	11654	17	1.90
SPACER, idler lock	14232	16	.85
SPRING, Claw tension	9052	17	.10
SPRING, retaining	14270	17	.10
SPRING, sound roller tension	14317	16	.10
SPRING, upper sound roller tension	14381	19	.10
SPROCKET, chain assembly	14101	19	2.00
SPROCKET, film and shaft assembly	14102	15	3.00
STOP, loop setter	14324	16	.25
STUD, lamphouse	14278-MP9	15	.20
TILT JACK assembly	14003-CC	15	14.00
TILT JACK housing subassembly	11138-AA	Not Shown	2.75

*''Shown on Page'' refers to page number in DeVry ''15'' Operating and Service Manual.

Minimum Dealer Order - $3.00 Net

SPEAKER PARTS

Description	Part Number	Shown On Page*	List Price
PLUG, speaker	14326-M3	14	$ .55
SPEAKER, 6" permanent magnet (less door)	14336	14	9.50

AMPLIFIER PARTS

CODE				
	RESISTORS			
R1, R2	240,000 ohm, 1/2 w. resistor	4205	23	.20
R3, R5, R7, R9, R15, R16, R21, R22, R29	510,000 ohm, 1/2 w. resistor	4197	23	.20
R4	15,000 ohm, 1/2 w. resistor	15962	23	.20
R6	200,000 ohm, 1/2 w. resistor	4032	23	.20
R8, R14	6,200 ohm, 1/2 w. resistor	14355	23	.20
R10, R11	2-9 meg., dual potentiometer	3285	23	1.50
R12, R19	10,000 ohm, 1/2 w. resistor	4344	23	.20
R13	1/2 meg. pot. W/sw.	3284	23	1.35
R17	5,100 ohm, 1/2 w. resistor	3844	23	.20
R18, R20	100,000 ohm, 1/2 w. resistor	4198	23	.20
R23	75,000 ohm, 1/2 w. resistor	3851	23	.20
R24	5,100 ohm, 1 w. resistor	4015	23	.30
R25, R26, R27	500-150-750 ohm, 5 w. resistor	14479	23	2.00
R28	1 meg., 1/2 w. resistor	4020	23	.15
	CAPACITORS			
C1, C3	.002 mfd., 200 v. capacitor	3826	23	.30
C2	.1 mfd., 200 v. capacitor	4520	23	.25
C4, C5	.005 mfd., 200 v. capacitor	14476	23	.30
C7, C11, C15, C19	20-20-20-20 mfd., 450 v.	14477	23	3.00
C8	.001 mfd., 400 v. capacitor	14477	23	.30
C9	.0005 mfd., 400 v. capacitor	14478	23	.30
C10, C13, C14	.01 mfd., 400 v. capacitor	3294	23	.20
C16, C17, C18	20-20-20 mfd., 450-450-25 w. v. elec. cap.	3280	23	2.00
C20	.1 mfd., 400 v. capacitor	4217	23	.50
C21	.01 mfd., 200 v. capacitor	14475	23	.30
C22	.0005 mfd., 400 v. capacitor	4235	23	.20
	RECEPTACLES			
P1	P.E. cell input receptacle	3892	23	.75
P2	Speaker output receptacle	14348	23	.75
P3	Line input receptacle	11612	23	1.40
P4	Power transformer connect.	11739	23	.25
P5	6-pin connector	4077	23	1.65
P6	Oscillator receptacle	14348	23	.75

Amplifier, Complete Assembly – No. 14009-CC – $120.00

CODE	Description	Part Number	Shown On Page*	List Price
		TUBES, LAMP AND SOCKETS		
V1, V2	12AX7 tube	14331	23	$ 2.40
V3, V4, V5	6AQ5 tube	14454	23	2.00
V6, V7	6X4 tube	14455	23	1.50
S1, S2	9-pin tube socket turret	12838	23	1.50
S3, S4, S5, S6, S7	7-pin tube socket	14351	23	1.75
S8	Octal socket	4297	23	.30
		TRANSFORMERS, JACKS, SWITCHES AND FUSES		
T1	Power transformer	14456	23	12.50
T2	Output transformer	14457	23	6.75
T3	Oscillator coil	12974	23	1.00
T4	Filter choke	14460	23	2.50
J1	Micro, input jack	4569	23	.50
J2	Phono, input jack	4569	23	.50
SW1	Power switch	Part of R13	23	
SW2	Sound-Silent Switch	4519	23	.80
SW3	Motor-lamp switch	11897	23	5.00
F1	Line fuse - 3AG, 2A	4063	23	.06
FP1	Fuse post	3964	23	.50

DeVry Corporation

1111 ARMITAGE AVE. CHICAGO 14, ILL., U.S.A.

Branches in New York and Hollywood. Established in 1913

Printed in U.S.A.